



Reference Formula

Created Date: 2019/12/27.
Last Save Date: 6/15/20 1:47 PM

Carbitol 卸妝凝露(Siltouch)

EP-SC-CL-0074A_V1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
A	ACULYN™ Siltouch Rheology Modifier¹	Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer (and) Dimethicone (and) Trideceth-6 (and) PEG/PPG-18/18 Dimethicone	2.50%	Emulsifier
	D.I Water	D.I Water	64.60%	
B	ERCAREL IPP V¹⁴ FZ-3196 Volatile Alkyl Methyl Siloxane Fluid¹ PMX-0245 Cyclopentasiloxane¹	Isopropyl Palmitate Caprylyl Methicone Cyclopentasiloxane	7.50% 5.00% 10.00%	Emollient Emollient Emollient
C	Glydant Plus Liquid	DMDM Hydantion & Iodopropynyl Butyl Carbamate	0.30%	Preservative
	CARBITOL™ Solvent JSQI¹	Ethoxydiglycol	10.00%	Solubilizer
D	Perfume	Perfume	0.10%	Fragrance

PROCEDURE

1. Prepare Phase A and Phase B separately.
2. Add Phase B to Phase A under stirring.
3. Final added Phase C and Phase D to the main tank stirring until mixed completely.

SPECIFICATION

APPEARANCE	: white cream	
VISCOSITY	: approx. 9,133 (54.8%) ± 10%	(RVDV-E, RV6, 60rpm, 3 min, 25°C)
pH	: approx. 5.82 ± 0.5	(25°C)

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

